

ENGR 498: Design for the Internet of Things – UART and Serial

Dr. Jason Forsyth

Department of Engineering


James Madison University

Communications

- Large number of microprocessor peripherals enable communication with external devices
 - USART, i2c, SPI, CAN, Ethernet...etc.
- Each communication method provides various speeds, payload sizes, reliability, pin count...etc.
- Broadly categorized into *serial* or *parallel* communication methods
 - Serial = data is sent bit by bit in order
 - Parallel = data is whole word at a time

Serial versus Parallel Interfaces


- Each interface provides a certain *bandwidth* (bits per second) that can be transmitted
 - Parallel: 8 bits every second = 8 bps
 - Serial: 1 bit * 8 Hz = 8 bps
- Parallel interfaces can have higher bandwidth (due to multiple data lines), however cost more (pins, traces, power...etc.)
- Parallel interfaces have fallen out of favor in microprocessors.
 - Serial dominates now due to speeds.
 - When was the last time you used a LPT cable?



Half and Full Duplex

- Interfaces also described by direction/concurrency of transactions that can take place
- Half-Duplex: only send OR receive at any one time
- Full-Duplex: can send AND receive at the same time


Full Duplex Communication



Full Duplex : Serial Peripheral Interface (SPI)
Dedicated Master In and Slave In lines

Half Duplex Communication

FIGURE 4-2: ACKNOWLEDGE TIMING



i2C: Only one transmission/reception at any one time


USART

Universal Synchronous/Asynchronous Receiver Transmitter


UART/USART

- Most common serial peripheral for microprocessors
- Generally will find as UART (asynchronous only) but advanced USARTs are available to perform asynchronous (UART) and synchronous (SPI, i2C...etc.) transmission
- Will focus on UART abilities for this lecture, even while using USART peripheral


Universal Asynchronous Transmitter Receiver



- Simple two pin interface: transmit (TX) and Receive (RX)
- Asynchronous: no clock or synchronizing signal. Both devices maintain their own timing
 - Inaccurate timing can lead to errors at higher rates
- Coordination information in payload
 - Reduces effective data rate



UART TX/RX Structure



- Packet initiated with START bit. TX signal is HIGH until driven LOW
- Fixed number of DATA bits (D0-D15) are clocked out. Optional PARITY bit for EVEN/ODD parity
- Transmission ends with STOP bit. TX held HIGH afterwards.

UART Transmission Parameters


- Baud Rate = rate at which bits are transmitted
 - Typical rates: 9600, 57600, 115200
- Data bits = number of data bits to be transmitted (generally 8 or 9)
- Parity = whether parity is disabled, EVEN, or ODD
- Stop bits = number of stop bits to transmit (0.5 - 2)
- Generally specified as 9600 8N1 (9600 baud, 8 data bits, No Parity, 1 Stop bit)

UART ≠ Serial ≠ RS-232 ≠ TTL Levels

- The word *serial* is used to describe many interfaces; not all are compatible
- “I used the serial interface on my Arduino” means “I used the UART0 on my ATmega”. Voltage levels are probably 3V-5V
- “I used the serial port on my PC” means “I used the serial/COM port off my mother board”. Voltage levels are probably -15V to 15V
- “I connected my Arduino to the PC through the serial port”.
 - USB voltage levels are 0V to 5V
 - No, you used the Arduino UART and the FTDI converter chip to send UART packets to your PC via the USB interface. Also a nice driver on your PC made the Arduino look like a serial/COM port.
- </rant>

RS-232 Signaling Levels

- Same data structure
- Signal levels are +15V to -15V
- **Will break your processor!**
- Signal levels used for PC “serial” port




Baud Rate and Communication Errors

Table 18-6. Examples of UBRRn Settings for Commonly Used Oscillator Frequencies


Baud Rate [bps]	$f_{osc} = 8.0000\text{MHz}$				$f_{osc} = 11.0592\text{MHz}$				$f_{osc} = 14.7456\text{MHz}$			
	U2Xn = 0		U2Xn = 1		U2Xn = 0		U2Xn = 1		U2Xn = 0		U2Xn = 1	
	UBRR	Error	UBRR	Error	UBRR	Error	UBRR	Error	UBRR	Error	UBRR	Error
2400	207	0.2%	416	-0.1%	287	0.0%	575	0.0%	383	0.0%	767	0.0%
4800	103	0.2%	207	0.2%	143	0.0%	287	0.0%	191	0.0%	383	0.0%
9600	51	0.2%	103	0.2%	71	0.0%	143	0.0%	95	0.0%	191	0.0%
14.4k	34	-0.8%	68	0.6%	47	0.0%	95	0.0%	63	0.0%	127	0.0%
19.2k	25	0.2%	51	0.2%	35	0.0%	71	0.0%	47	0.0%	95	0.0%
28.8k	16	2.1%	34	-0.8%	23	0.0%	47	0.0%	31	0.0%	63	0.0%
38.4k	12	0.2%	25	0.2%	17	0.0%	35	0.0%	23	0.0%	47	0.0%
57.6k	8	-3.5%	16	2.1%	11	0.0%	23	0.0%	15	0.0%	31	0.0%
76.8k	6	-7.0%	12	0.2%	8	0.0%	17	0.0%	11	0.0%	23	0.0%
115.2k	3	8.5%	8	-3.5%	5	0.0%	11	0.0%	7	0.0%	15	0.0%
230.4k	1	8.5%	3	8.5%	2	0.0%	5	0.0%	3	0.0%	7	0.0%
250k	1	0.0%	3	0.0%	2	-7.8%	5	-7.8%	3	-7.8%	6	5.3%
2.5M	2	0.2%	4	0.2%	2	0.0%	5	0.0%	4	0.0%	6	0.0%

So we send data over the
USART to the Computer?

Actually no...




ISSUE	ADAFRUIT INDUSTRIES		© 2015
DRAWN KTOWN	TITLE		REV B
CHECKED >CHECKED	DATE 1/1/2018 11:51:20 PM		DRG NO >DRGNO
DATE >DATE	FILE: Itsy Bitsy 32u4 3V rev B		PAGE: 1/1



In addition, some pins have specialized functions:

- Serial: 0 (RX) and 1 (TX). Used to receive (RX) and transmit (TX) TTL serial data using the ATmega32U4 hardware serial capability. Note that on the Micro, the Serial class refers to USB (CDC) communication; for TTL serial on pins 0 and 1, use the Serial1 class.

What if I don't support USB....



Sending and Receiving using the USART

Serial

Serial communication on pins TX/RX uses TTL logic levels (5V or 3.3V depending on the board). Don't connect these pins directly to an RS232 serial port; they operate at +/- 12V and can damage your Arduino board.

Serial is used for communication between the Arduino board and a computer or other devices. All Arduino boards have at least one serial port (also known as a UART or USART): `Serial`. It communicates on digital pins 0 (RX) and 1 (TX) as well as with the computer via USB. Thus, if you use these functions, you cannot also use pins 0 and 1 for digital input or output.

You can use the Arduino environment's built-in serial monitor to communicate with an Arduino board. Click the serial monitor button in the toolbar and select the same baud rate used in the call to `begin()`.

The [Arduino Mega](#) has three additional serial ports: `Serial1` on pins 19 (RX) and 18 (TX), `Serial2` on pins 17 (RX) and 16 (TX), `Serial3` on pins 15 (RX) and 14 (TX). To use these pins to communicate with your personal computer, you will need an additional USB-to-serial adaptor, as they are not connected to the Mega's USB-to-serial adaptor. To use them to communicate with an external TTL serial device, connect the TX pin to your device's RX pin, the RX to your device's TX pin, and the ground of your Mega to your device's ground.

The [Arduino Due](#) has three additional 3.3V TTL serial ports: `Serial1` on pins 19 (RX) and 18 (TX); `Serial2` on pins 17 (RX) and 16 (TX), `Serial3` on pins 15 (RX) and 14 (TX). Pins 0 and 1 are also connected to the

Functions

- `if (Serial)`
- `available()`
- `availableForWrite()`
- `begin()`
- `end()`
- `find()`
- `findUntil()`
- `flush()`
- `parseFloat()`
- `parseInt()`
- `peek()`
- `print()`
- `println()`
- `read()`
- `readBytes()`
- `readBytesUntil()`
- `readString()`
- `readStringUntil()`
- `setTimeout()`
- `write()`
- `serialEvent()`

Functions

- if (Serial)
- available()
- ~~- availableForWrite()~~
- begin()
- end()
- ~~- find()~~
- ~~- findUntil()~~
- ~~- flush()~~
- ~~- parseFloat()~~
- ~~- parseInt()~~
- peek()
- print()
- println()
- read()
- readBytes()
- ~~- readBytesUntil()~~
- ~~- readString()~~
- ~~- readStringUntil()~~
- setTimeout()
- write()
- serialEvent()

There's a difference between write() and print()

Binary/Byte Operations

- Read()
- Write()
- Peak()

Char / String Operations

- Print()
- Println()

Simple Serial/UART Programs

```
void setup() {  
  
    //configure the Serial port for 9600 baud  
    Serial.begin(9600);  
  
    //wait until it's ready  
    while(!Serial){}  
}  
  
void loop()  
{  
  
    //is there any data to read?  
    while(Serial.available>0)  
    {  
        //read one of the bytes  
        byte data = Serial.read();  
  
        //send it back where it came from!  
        Serial.write(data);  
    }  
}
```

```
void setup() {

    //configure the Serial port for 9600 baud
    Serial.begin(9600);

    //wait until it's ready
    while(!Serial){}
}

//create an array of fixed length
const int len=8;
byte dataArray[len];



void loop()
{

    //is there any data to read?
    int i=0;
    while(Serial.available>0)
    {
        //read one of the bytes
        byte data = Serial.read();

        //read data into array (avoiding overflow)
        dataArray[i%len]=data;



        //increment counter
        i++;
    }
}
```

Why We'll Need This...





USB/Serial Interface
(Digital Pins 0 and 1)



```
void loop()
{
```

```
    //If any data comes in from the terminal, send it to the Basestation
```

```
    if (Serial.available())
```

```
    {
```

```
        while (Serial.available())
```

```
        {
```

```
            char c = Serial.read();
```

```
            XBee.write(c);
```

```
        }
```

```
    }
```

```
    //Data received from the Basestation, bring to our serial terminal.
```

```
    if (XBee.available())
```

```
    {
```

```
        while (XBee.available())
```

```
        {
```

```
            char c = XBee.read();
```

```
            Serial.write(c);
```

```
        }
```

```
    }
```

```
}
```